

EVNT-CWR TROUBLESHOOTING GUIDE

	PROBLEM	CORRECTION	COMMENTS
1	LID DOES NOT OPEN WHEN YOU PLACE YOUR HAND IN FRONT OF SENSOR	CHECK BATTERIES OR REPLACE	Use GOOD QUALITY BATTERIES
2	LID GOES UP BUT DOES NOT COME DOWN. RED LIGHT BLINKING.	HOLD HAND ABOVE SENSOR FOR 5 SECONDS	THIS FEATURE IS FOR REPLACING BAG
3	YOU HEAR MOTOR TURNING BUT NOTHING HAPPENS	MECHANICAL PROBLEM	CHECK CONNECTING ARM TO INSIDE OF LID
4	LID OPENS AND CLOSES BY IT SELF	MAKE SURE YOU HAVE AT LEAST 2 FEET OF CLEARANCE IN FRONT OF UNIT	WILL ACTIVATE IF PLACING A REFLECTIVE OBJECT RIGHT IN FRONT
6	FOUL ODOR COMING FROM UNIT	REPLACE BAG OR REMOVE CONTENTS	SEE BAG REPLACEMENT PROCEDURE
7			
8			
9			