



26301 Curtiss-Wright Parkway Suite 200 • Cleveland, OH 44143

**SUBJECT: ADA Guide: Dual #1(D1), Series Sanitary Napkin/Tampon Vendor Installation**

The ADA Guidelines to be used for installing Hospeco Brands Group's D1 Series Napkin/Tampon Vendors are as follows:

- Access to vendor should be 39" - 44" above the floor to allow forward and side reach by persons in wheelchairs.
- Unit should be operable with one hand and without tight grasping, pinching or twisting of the wrist.
- Activation of the lever should not require more than 5 lbs. of force when unit is completely filled.
- Do not mount Vendor in a Circulation Path. A Circulation Path is defined by ADAAG as: "An exterior or interior way of passage provided for pedestrian travel, including but not limited to, walks, hallways, courtyards, elevators, platform lifts, ramps, stairways, and landings."

**Note:** Hospeco Brands Group's D1 Series Napkin/Tampon Vendor mechanisms meet the above ADA guidelines. The coin mechanism works with a 180° turn. A clenched fist can draw down the Z handle in a straight line, without twisting, with less than 5 lbs. of force. Mounting of unit should be 74" to top of unit floor, 60" for handicapped accessibility.

When installing unit, make sure to mount directly to the wall according to "Mounting Template". Vendor must be secured with all four mounting apertures. The capacity of all models is: 15 each #4 Sanitary Napkin Boxes and 22 each vended tampons.

Hospeco Brands Group 800•942•9199

Source for Definition: <https://www.access-board.gov/guidelines-and-standards>